

Dual v.2.31

Power: DC 9V Center negative

	Mode	A	B	AB	A hold	B hold	AB hold
Red	FS MODE	FS4	FS5	TAP&TUNER MODE	Preset down	Preset up	SNAPSHOT MODE
Blue	TAP&TUNER MODE	Tuner on/off	Tap	PRESET MODE	FS MODE		SNAPSHOT MODE
Purple	PRESET MODE	Preset down	Preset up	SNAPSHOT MODE	FS4	FS5	FS MODE
Green	SNAPSHOT MODE	Snapshot 1	Snapshot 2	Snapshot 3	TAP&TUNER MODE	PRESET MODE	FS MODE

Controller setup via USB connection (USB socket is under bottom cover)

kgmidicontrollers.com/terminal

command:	value:	Description	Default
hxchannel	1-16	MIDI Channel	1
holdtime	10-2550 (ms)	Button long press time	500
layout	0/1	Swap buttons	0

examples: hxchannel 3 will set MIDI Channel to 3
 holdtime 700 will set button long press time to 700 milliseconds

**To switch orientation of the controller (swap buttons A&B functions)
press and hold button A or B while powering on the controller.**